FF-800 Technical Manual

Technical Data for the FF-800 Repeater Control System

Revised October 6, 2024 Copyright © 2001-2024, All Rights Reserved



"AFFORDABLE REPEATER CONTROL SOLUTIONS"

FF-800 Technical Manual

TABLE OF CONTENTS

Warranty	1
FF-800 Parts List and Schematic	2
FF-800 Connector Pinouts (Revision H+)	15
FF-800 Connector Pinouts (Revision E/G)	
FF-180 Chassis	
Basic Installation	23
Advanced Istallation	24
FF-180 Chassis Connector Pinouts	27
FF-800 mini-DIN Connector Pinouts	30
mini-DIN Connector Assembly Detail	31
Molex Connector Assembly Detail	32
Doug Hall RBI-1 connection	
FF-8010 Display Module	35
Microphone Header Wiring	
FF-8010 Parts List	35
FF-8010 Schematic	
FFlash (revC) Parts List	37
FFlash (rev C) Schematic	38
FFlash (rev C) Component Placement	

Warranty

FF Systems warrants its products to be free from defects for one year from the date of shipment. FF Systems may opt to repair or replace (at our option) any defective product. FF Systems does not warrant any defect due to lightning or other natural disaster. Any user modifications or repairs to any product sold by FF Systems will void this warranty. All returns must be accompanied by a Return Material Authorization (RMA) number provided by FF Systems prior to shipment. Shipments that do not have the proper return authorization prominently noted on the outside of the package will not be accepted. The purchaser is responsible for all shipping charges for any service procedure(s) performed by FF Systems (including warranty service).

30 Day Money Back Guarantee

FF Systems offers a 30 day trial period on all products. The 30 day trial begins 5 calendar days after shipment from FF Systems. If the purchaser decides to return a product they must contact FF Systems for a Return Material Authorization (RMA) number on or before 6:00pm central time within 35 calendar days of the original shipment date. The purchaser then has fourteen additional days to return the merchandise to FF Systems. FF Systems claims no liability for lost or mis-directed shipments. The purchaser is responsible for all shipping charges.

Product Condition

Products must be in new condition or warranty repairable to qualify for refund. If merchandise incurs damage not covered under warranty, the refund will be delayed until the unit has been repaired and the cost of that repair shall be deducted from the refund. FF Systems is not responsible for damages incurred during shipment -- the purchaser should insure the merchandise for the purchase amount to avoid possible loss due to damage during shipment.

Contact Address

FF Systems

e-mail: joeh@ke0ff.org

web: www.ke0ff.org

www.github.com/ke0ff


FF-800 Parts List	
Reference Designator	Component Description
C1, 24, 36, 42, 43, 44, 45, 58, 59, 60, 63, 65, 69, 73, 76, 78, 81, 83	10 UF electrolytic capacitor, 25V
C2, 17, 20, 29, 37, 40, 41, 46, 62, 64, 67, 68, 70, 71, 72, 74, 75, 77, 79, 80, 82, 87	0.1 UF ceramic capacitor, 50V
C3, 4, 5, 8, 9, 10, 11, 12, 13, 14, 18	1.0 UF non-polarized electrolytic capacitor, 25V
C6, 7, 22, 23, 26, 30, 31	100 PF ceramic capacitor, 50V
C16, 19	470 PF ceramic capacitor, 50V
C21	33 PF ceramic capacitor, 50V
C25	0.001 UF ceramic capacitor, 50V
C28	1.0 UF ceramic capacitor, 200V
C32, 34	330 UF electrolytic capacitor, 25V
C33, 35, 38, 39	100 UF electrolytic capacitor, 35V
C47, 48	22 PF ceramic capacitor, 50V
C56, 57	220PF ceramic capacitor, 2KV
C61, 66	1.0 UF tantalumn capacitor, 16V
C84, 86	0.0047 UF ceramic capacitor 50V (not installed)
C85	4.7 UF electrolytic capacitor, 25V (not installed)
C89	0.01 UF ceramic capacitor, 50V
C90	0.1 UF ceramic chip capacitor, 50V
CR1	8.000MHz ceramic resonator w/ caps
CR2	3.5795MHz crystal, HC-49U
CR3	3.2768MHz crystal, HC-49U


FF-800 Parts List	
Reference Designator	Component Description
D1	LM4040-5.0, 5V ref. I.C.
D2 - 25	5.1V zener diode, 1W
D28, 29	qty 2, 1N914 diodes in series
D30, 31, 32	1N4001 diode
D36	BAS16 diode, SOT-23
DP1	DS1267-100 digital pot, 100K
DP2 - 4	DS1267-010 digital pot, 10K
L1	1000uH coil
LED1	Red LED, SMD 1206 pkg
Ol1 - 3	Opto-isolator, NPN 4 pin DIP
Q1, 2, 4, 5	2N2907 PNP transistor
Q3	2N2222 NPN Transistor
Q7, 8	2N2907 PNP transistor, SOT-23
Q9	2N2222 NPN transistor, SOT-23
R01	10M ohm, 1/4W resistor
R02	3.3 K ohm, 1/4W resistor
R03	4.7K ohm, 1/4W resistor
R5 - 28	330 ohm, 1/4W resistor
R29, 30, 31, 32, 63	51K ohm, 1/4W resistor
R33, 101	5.1K ohm, 1/4W resistor
R34, 35, 38, 39, 42, 57, 64	100K ohm, 1/4W resistor
R36, 37, 40, 41	750K ohm, 1/4W resistor


FF-800 Parts List	
Reference Designator	Component Description
R43, 49, 50, 52	6.2K ohm, 1/4W resistor
R44 - 48, 65, 66, 82, 83, 84	100 ohm, 1/4W resistor
R51	6.2K ohm, 1/8W resistor
R53 - 56, 58 - 61	20K ohm, 1/4W resistor
R62, 69	470 ohm, 1/4W resistor
R67, 85	10K ohm, 1/4W resistor
R68	18K ohm, 1/4W resistor
R70 - 73	510 ohm, 1/4W resistor
R86	2.4K ohm, 1/4W resistor
R87	12K ohm, 1/4W resistor
R89 - 94, 98, 99	20K ohm, 1/8W resistor
R95, 96	36K ohm, 1/8W resistor
R97, 100	1K ohm, 1/8W resistor
R103	330 ohm, 1/8W resistor
RLY1	DPDT Relay, 12V coil
RP1, 5	10K X 7 resistor pack
RP2 - 4	22K X 9 resistor pack
RP6	10K X 5 resistor pack
RP7	1K X 4 (indiv) resistor pack
RP8	2.2K X 5 resistor pack
SW1	mini push button switch, momentary contact, normally open
SW2	4 position DIP switch
T1	MIDCOM 671-0236 or equiv.


FF-800 Parts List	
Reference Designator	Component Description
U1	MC68HC711E9CFN2 microcontroller I.C.
U2	74HC373 hex latch I.C.
U3	28F256 32K x 8 FLASH memory I.C.
U4	28F010 64K x 8 FLASH memory I.C.
U5	STK11C88 32K x 8 NVRAM I.C.
U6	48T1512 2K timekeeper NVRAM I.C.
U7 - 9	MC68B21P PIA I.C.
U10	74HC00 quad NAND gate I.C.
U11, 12	74HC139 dual 2 input MUX I.C.
U13	74HC138 3 input MUX I.C.
U14, 15	MC34064 low voltage monitor I.C.
U16	CD4040 12 bit ripple counter I.C.
U17, 18	TL064 quad OPAMP I.C.
U19, 20	CD4051 1 of 8 analog MUX I.C.
U21, 22	M8870 DTMF receiver I.C.
U23	CD4066 quad analog switch I.C.
U24	LF353 dual OPAMP I.C.
U25, 26	M7805 5V regulator I.C., 1A
U27	78L05 5V regulator I.C., 100mA
U28	MAX660 dc-dc converter I.C.
U29	MAX232CPA RS-232 line xcvr I.C.
U30	TSP53C30 speech synthesizer I.C.
U31, 33	MF4-50 switched capacitor filter I.C.
U35, 36	TPIC6273 quad open drain, high current driver I.C.
Z1	15V tranzorb, 600W
Z2	PTC fuse, 100mA
Z3, 4, 6	6.8V tranzorb, 600W
Z 5	gas tube, dual spark gap


<u>Connector</u> <u>Designator</u>	Connector Type	<u>Function</u>
P1	10 position dual row header, w/ shroud	DC POWER IN
P2	9 pin Molex header	RXIN
P4	9 pin Molex header	TX OUT
P5	10 position dual row header, w/ shroud	LOGIC OUTPUT
P6	4 pin SIP header	All ports Audio DELAY
P6A	4 pin SIP header	Port A only Audio DELAY
P7	10 position dual row header, w/ shroud	FF-800 SPI
P8	7 pin Molex header	PHONE I/O
P9	10 position dual row header, w/ shroud	INPUTS
P10	10 position dual row header, w/ shroud	VOTER COS
P11	4 pin mini-DIN female	RX1
P12	4 pin mini-DIN female	RX2
P13	4 pin mini-DIN female	RX3
P14	4 pin mini-DIN female	RX4
P15	4 pin mini-DIN female	TX1
P16	4 pin mini-DIN female	TX2
P17	4 pin mini-DIN female	TX3
P18	4 pin mini-DIN female	TX4
P19	10 position dual row header, w/ shroud	CTCSS IN
P20	4 pin mini-DIN female	DVR AUD
P21	4 pin RJ11 jack, right angle	Phone line in
P22	9 pin Molex header	DPOTS
P22A	10 position dual row header, w/ shroud	DPOTS
P23	10 position dual row header, w/ shroud	DISPLAY
P24	6 pin mini-DIN female	AUX PATCH
P25	10 position dual row header, w/ shroud	DVR
P26	3 pin Molex header	LOCAL OUT
P27	3 pin Molex header	RS232
P27A	16 position dual row header, w/ shroud	RS232 (alt)
P28	10 position dual row header, w/ shroud	FFLASH




















FF-800 Connector Pinouts (Revision H+)

P1 (10) Power	pin dual row)		oin Molex) nitter Ouputs
Pin#	Description	Pin#	<u>Description</u>
1 2 3 4 5 6 7 8 9	GND GND GND +5V out GND -5V out GND GND GND H12V in H12V in	1 2 3 4 5 6 7 8 9	TXA audio output ~TXA PTT output TXB audio output ~TXB PTT output TXC audio output ~TXC PTT output TXD audio output ~TXD PTT output GND
P2 (9 r	oin Molex)	Logic (pin dual row)
	er Inputs	Logic	Jupuis
Pin#	<u>Description</u>	Pin#	<u>Description</u>
1 2 3 4 5 6 7 8 9	RXA audio input RXA COS input RXB audio input RXB COS input RXC audio input RXC audio input RXC COS input RXD audio input RXD coS input RXD COS input	1 2 3 4 5 6 7 8 9	Output# 1 Output# 6 Output# 2 Output# 7 Output# 3 Output# 8 Output# 4 GND Output# 5 GND
P3 (9 p Aux. Ii	oin Molex) nputs	, -	oin single row) Audio Delay
Pin#	<u>Description</u>	Pin#	<u>Description</u>
1 2 3 4 5	Aux. DTMF audio input Local RX audio input Local RX COS input Cntl. RX audio input Cntl. RX COS input	1 2 3 4	Audio to delay module Audio from delay GND +12V
6 7 8	Command Trigger 1 in Command Trigger 2 in Spare audio input		pin single row) Audio Delay
9	GND	Pin#	<u>Description</u>
		1 2 3 4	Audio to delay module Audio from delay GND +12V

P7 (10pin dual row) SPI Bus

Pin#	<u>Description</u>
1 2 3 4 5	MOSI GND SPCK GND MISO GND
7 8 9 10	~strobe1 ~RQST strobe2 ~reset

P8 (7 pin Molex) Phone Line I/O

Pin#	<u>Description</u>
1 2 3 4 5 6	TIP RING n/c BUSYIN+ BUSYIN- BUSYOUT+ BUSYOUT-

P9 (10pin dual row) Analog Inputs

Pin#	<u>Description</u>
1 2	Command Trigger 1 in Analog#2 in
3	Command Trigger 2 in
4	Analog#3 in
5	Command Trigger 3 in
6	Analog#4 in
7	Command Trigger 4 in
8	GND
9	Analog#1 in
10	GND

P10 (10pin dual row) Voter Logic Inputs

<u>Pin#</u>	Description
1 2	VOTE#1 VOTE#6
3	VOTE#2
4 5	VOTE#7 VOTE#3
6	VOTE#8
7	VOTE#4
8	GND
9	VOTE#5
10	GND

P11 (4 pin mini-DIN) RX Port A

Pin#	<u>Description</u>
1	Port A COS
2	Port A RX audio
3	GND
4	Port A CTCSS

P12 (4 pin mini-DIN) RX Port B

Pin#	<u>Description</u>
1	Port B COS
2	Port B RX audio
3	GND
4	Port B CTCSS
P13 (4	pin mini-DIN)
RX Po	rt C
Pin#	Description

Pin#	<u>Description</u>
1 2	Port B COS Port B RX audio
3	GND
4	Port B CTCSS

P14 (4 RX Por	pin mini-DIN) rt D		0 pin dual row) S Logic Inputs
Pin#	<u>Description</u>	<u>Pin#</u>	<u>Description</u>
1 2 3 4	Port D COS Port D RX audio GND Port D CTCSS	1 2 3 4 5	Cntl. RX CTCSS in Port D CTCSS in Local CTCSS in GND Port A CTCSS in
P15 (4 TX Por	pin mini-DIN) rt A	6 7 8 9	Spare audio in Port B CTCSS in GND Port C CTCSS in
Pin#	<u>Description</u>	10	GND
1 2 3 4	~Port A PTT Port A TX audio GND Logic output# 1	EXT	oin mini-DIN) OVR Audio
P16 (4 TX Por	pin mini-DIN) rt B	<u>Pin#</u> 1 2	Description DVR audio in A (rec DVR audio out (play)
Pin#	<u>Description</u>	3 4	GND DVR audio in B (rec)
1 2 3 4	~Port B PTT Port B TX audio GND Logic output# 2	P21 (4 Phone Pin#	pin RJ-11) Line Description
P17 (4 TX Por Pin#	pin mini-DIN) rt C <u>Description</u>	1 2 3 4	n/c TIP RING n/c
1 2 3 4	~Port C PTT Port C TX audio GND Logic output# 3		0 pin dual row) igital Pots Description
P18 (4 TX Por	pin mini-DIN) rt D	1 2	Aux pot HI P_CLK
Pin# 1 2 3 4	Description ~Port D PTT Port D TX audio GND Logic output# 4	3 4 5 6 7 8 9	Aux pot ARM P_STROBE Aux pot LO n/c GND GND P_DATA GND

P23 (10 pin dual row) Display

Pin#	<u>Description</u>
1 2 3 4	D_STROBE GND D_CLK GND
5 6	D_DATA Lcl RX Audio in
7 8 9	+5V Lcl RX COS +12V
10	-5V

P24 (6 pin mini-DIN) Link Patch

Pin#	<u>Description</u>
1	GND
2 3	~BUSY in AUX audio (to patch)
4	~RING
5	Audio (from patch)
6	~BUSY out
7	GND

P25 (10 pin dual row) DVR Audio/PWR

Pin#	<u>Description</u>
1 2	DVR audio in A (rec) GND
3	DVR audio out (play)
4	GND
5	GND
6	GND
7	DVR audio in B (rec)
8	+12V
9	GND
10	+12V

P26 (3 pin Molex) Local TX Port

Pin#	<u>Description</u>
1	LCL Audio out
2	~LCL_PTT
3	GND

P27a (16 pin dual row) RS-232 Serial I/O Port

Pin# Description

4	
1	n/c
2	n/c
2 3	FF-800 serial in
4	n/c
5	FF-800 serial out
6	n/c
7	Jump pad 4
8 9	n/c
9	Jump pad 5
10	n/c
11	Jump pad 6
12	n/c
13	GND
14	Jump pad 20
15	Jump pad 8
16	n/c

P28 (10 pin dual row) FFLASH Control

Pin#	<u>Description</u>
1	+5V
2	Vpp
3	~reset
4	GND
5	MODA
6	MODB
7	(jumper to Sin)
8	(jumper to GND)
9	(jumper to GND)
10	(jumper to GND)

FF-800 Connector Pinouts (Revision E/G)

P1 (7 p Power	oin Molex)	_	oin Molex) nitter Ouputs
Pin#	<u>Description</u>	Pin#	Description
1 2 3 4 5 6 7	GND GND GND H12V in +5V out -5V out	1 2 3 4 5 6 7 8 9	TXA audio output ~TXA PTT output TXB audio output ~TXB PTT output TXC audio output ~TXC PTT output TXD audio output ~TXD PTT output GND
	oin Molex) er Inputs	P5 (9 p Logic (oin Molex)
	_		-
Pin#	<u>Description</u>	Pin#	<u>Description</u>
1 2 3 4 5 6 7 8	RXA audio input RXA COS input RXB audio input RXB COS input RXC audio input RXC COS input RXC COS input RXD audio input RXD of input RXD COS input RXD COS input RXD COS input	1 2 3 4 5 6 7 8 9	Output# 1 Output# 2 Output# 3 Output# 4 Output# 5 Output# 6 Output# 7 Output# 8 GND
P3 (9 p Aux. Ii	oin Molex) nputs	_	oin single row) Audio Delay
Pin#	<u>Description</u>	Pin#	<u>Description</u>
1 2 3 4 5 6 7 8	Aux. DTMF audio input Local RX audio input Local RX COS input Cntl. RX audio input Cntl. RX COS input Command Trigger 1 in Command Trigger 2 in Spare audio input GND	1 2 3 4	Audio to delay module Audio from delay GND +12V
		,	pin single row) Audio Delay
9		Pin#	<u>Description</u>
		1 2 3 4	Audio to delay module Audio from delay GND +12V

FF-800 Rev E/G Connector Pinouts

P7 (10 pin Molex) SPI Bus

Pin#	<u>Description</u>
1 2 3 4 5 6 7 8 9	MOSI SPCK MISO ~strobe1 strobe2 ~reset GND GND Spare audio in ~RQST in
10	regor in

P8 (7 pin Molex) Phone Line I/O

Pin#	<u>Description</u>
1	TIP
2	RING
3	n/c
4	BUSYIN+
5	BUSYIN-
6	BUSYOUT+
7	BUSYOUT-

P9 (7 pin Molex) Analog Inputs

Pin#	Description
1	Analog#1 in
2	GND
3	Analog#2 in
4	GND
5	Analog#3 in
6	GND
7	Analog#4 in

P10 (9 pin Molex) Voter Logic Inputs

Pin#	Description
1 2 3 4 5 6 7 8 9	VOTE#1 VOTE#2 VOTE#3 VOTE#4 VOTE#5 VOTE#6 VOTE#7 VOTE#8 GND

P11 (4 pin mini-DIN) RX Port A

Pin#	<u>Description</u>
1 2	Port A COS Port A RX audio
3	GND
4	Port A CTCSS

P12 (4 pin mini-DIN) RX Port B

1 Port B COS 2 Port B RX audie 3 GND
4 Port B CTCSS

P13 (4 pin mini-DIN) RX Port C

Pin#	<u>Description</u>
1 2	Port B COS Port B RX audio
3	GND
4	Port B CTCSS

P14 (4 pin mini-DIN) RX Port D

Pin#	<u>Description</u>
1	Port D COS
2	Port D RX audio
3	GND
4	Port D CTCSS

P15 (4 pin mini-DIN) TX Port A

Pin#	<u>Description</u>
1	~Port A PTT
2	Port A TX audio
3	GND
4	Logic output# 1

P16 (4 pin mini-DIN) TX Port B

Pin#	<u>Description</u>
1	~Port B PTT
2	Port B TX audio
3	GND
4	Logic output# 2

P17 (4 pin mini-DIN) TX Port C

Pin#	<u>Description</u>
1	~Port C PTT
2	Port C TX audio
3	GND
4	Logic output# 3

P18 (4 pin mini-DIN) TX Port D

Pin#	<u>Description</u>
1	~Port D PTT
2	Port D TX audio
3	GND
4	Logic output# 4

P19 (9 pin Molex) CTCSS Logic Inputs

<u>Pin#</u>	<u>Description</u>
1	Command Trigger 3 in
2	Command Trigger 4 in
3	Port D CTCSS in
4	Port C CTCSS in
5	Port B CTCSS in
6	Port A CTCSS in
7	Local CTCSS in
8	Cntl. RX CTCSS in
9	GND

20 (4 pin mini-DIN) EXT DVR Audio

Pin#	<u>Description</u>
1	DVR audio in A (rec)
2	DVR audio out (play)
3	GND
4	DVR audio in B (rec)

P21 (4 pin RJ-11) Phone Line

Pin#	Description
1 2 3	n/c TIP RING n/c

P22 (9 pin Molex) Ext. Digital Pots

Pin#	<u>Description</u>
1 2 3 4 5 6 7	P_DATA P_CLK P_STROBE GND Aux pot HI Aux pot ARM Aux pot LO
8	GND
9	GND

P23 (7 pin Molex)

Display

Pin#	<u>Description</u>
1 2 3	D_STROBE D_CLK D_DATA
4 5	-5V +5V
6	GND
7	+12V

P24 (6 pin mini-DIN) Link Patch

Pin#	<u>Description</u>
1 2 3 4 5 6 7	GND ~BUSY in AUX audio (to patch) ~RING Audio (from patch) ~BUSY out GND

P25 (4 pin Molex) DVR Audio

Pin# Description 1 DVR audio in A (rec) 2 DVR audio out (play) 3 GND 4 DVR audio in B (rec)

P26 (3 pin Molex) Local TX Port

Pin#	<u>Description</u>
1 2	LCL Audio out ~LCL PTT
3	GND _

P27 (3 pin Molex) RS-232 Serial I/O Port

Pin#	<u>Description</u>
1 2 3	FF-800 serial in FF-800 serial out GND

P28 (6 pin dual row) FFLASH Control

Pin#	<u>Descriptio</u>
1	+5V
2	~reset
3	MODA
4	Vpp
5	GND
6	MODB

FF-180 Chassis

The FF-180 chassis enclosure provides a convenient means for rack mounting the FF-800 system. The chassis includes cut-outs for DB-9 type connectors, provision for an optional LED display module, and has room for an FF-8070 DVR and up to 2 user supplied prototype cards. This manual describes the physical and electrical characteristics of the basic chassis along with installation instructions.

In addition to the connectors supplied with the FF-800, the FF-180 chassis includes the following connectors and accessories:

Quantity	<u>Description</u>
2	DB-9 female ribbon cable assemblies
4	Jack screws and associated hardware
1	Female DB-9, solder cup terminations
2	Male DB-9, solder cup terminations
3	DB-9 shielded hood
1	1A fuse (installed)

The user must supply suitable cable for completing the connection of the chassis to their system (reasonably good 4 and 9 conductor shielded cables are available from most electronic supply outlets).

The ribbon cable assemblies may be installed at the appropriate cut-out location(s) as desired. If needed, additional cables may be purchased from FF Systems.

Basic Installation

Using the FF-800 manual as a guide, construct mini-DIN cables for your receiver and transmitter. The only remaining connection required is the power connection on the FF-180. Using the female DB-9 supplied with the FF-180, connect +12V (nominal, +15V Max) to pin 1 of the DB-9. Connect ground to pins 6-9. Wrap the DB-9 connections with one or two layers of electrical tape and install the DB-9 hood. De-energize the +12V supply and install the DB-9 power connector at P208 on the chassis back panel. Use an ohm meter to check the power supply for shorts. If the ohm meter check is OK, energize the +12V supply and turn on the front panel power switch. The power LED should illuminate and the FF-800 should key up the TX and send its announcement message.

Advanced Istallation


The front/back and top views of the chassis are shown in figures 1 and 2, respectively. The placement of the FF-800 is such that the DIN type connectors (phone, P11-18, P20, and P24) are against the back of the chassis where they are accessed via round or square hole openings.

The remaining panel cut-outs are are rectangular and are designed to to accept a DB-9, or DB-15E (high density) connectors (male or female). Most of these cut-outs are labled, but have no connector installed. These labled cut-outs indicate that there is a pre-defined connector (i.e., one of the two DB-9 ribbon cables supplied) that may be installed which has a pinout described in the "Chassis Connector Pinouts" section. The un-labled cut-outs are available for user defined connections.


While the FF-800 manual does not describe the pinouts for the DB-9 connections, it does describe the signals and how they might be connected. Use the FF-800 manual as a guide in conjunction with the "Chassis Connector Pinouts" section to complete your installation.

Determine which functions are needed and install the DB-9 ribbon cable(s) in the appropriate cut-out(s). The other end of the cable connects to a shrouded connector on the FF-800 as indicated in the "Chassis Connector Pinouts" section.

Figure 3 illustrates the cable preparation dimensions for the DB-9 and DB-25 connectors. The heat shrink tubing can be omitted by splicing a short piece (3/4") of hook-up wire to the shield wire where it emerges from the cable sheath (the excess shield wire would then be trimmed with wire cutters). The strain relief must then secure the cable in the appropriate hood such that the shield splice can not short to any of the connector pins. When assembling the DB-9 connectors, the user should always connect the cable shield to pin 9 of the connector. Other ground pins included on some connectors represent SIGNAL ground and should not be used for shield group.



FF-180 Front Panel View



FF-180 Back Panel View

Figure 1




Figure 2. Chassis Top View

FF-180 Chassis Connector Pinouts


P201 (connect to P10) Voter Logic Inputs		P204 (connect to P9) Inputs			
Pin#	<u>Description</u>	FF-800 pin	Pin#	<u>Description</u>	FF-800 pin
1 2 3 4 5 6 7 8 9	Voted RX #1 COS Voted RX #2 COS Voted RX #3 COS Voted RX #4 COS Voted RX #5 COS Voted RX #6 COS Voted RX #7 COS Voted RX #8 COS GND	P10-1 P10-2 P10-3 P10-4 P10-5 P10-6 P10-7 P10-8 P10-9	1 2 3 4 5 6 7 8 9	Command Trigger #1 Command Trigger #2 Command Trigger #3 Command Trigger #4 Analog Input #1 Analog Input #2 Analog Input #3 Analog Input #4 GND	P3-6 P3-7 P19-1 P19-2 P9-1 P9-3 P9-5 P9-7
	(connect to P19) S Inputs			(connect to P22) I POT I/O	
Pin#	<u>Description</u>	<u>FF-800 pin</u>	Pin#	<u>Description</u>	FF-800 pin
1 2 3 4 5 6 7 8 9	Cntl RX CTCSS Input Lcl RX CTCSS Input RX A CTCSS Input RX B CTCSS Input RX C CTCSS Input RX D CTCSS Input GND Spare Audio to Mixer GND	P19-8 P19-7 P19-6 P19-5 P19-4 P19-3 P19-9 P3-8 P19-9	1 2 3 4 5 6 7 8 9	User POT HI User POT Arm User POT Low GND PDATout PCKout PRSTout GND	P22-5 P22-6 P22-7 P22-8 P22-1 P22-2 P22-3 P22-4
P203 (SPI Bu	(connect to P7)			(connect to P5) Outputs	
Pin#	<u>Description</u>	FF-800 pin	Pin#	<u>Description</u>	FF-800 pin
1 2 3 4 5 6 7 8	MOSI SPCK MISO ~STROBE1 ~STROBE2 ~RESET +5V ~RQST GND	P7-1 P7-2 P7-3 P7-4 P7-5 P7-6 P1-6 P7-10 P7-7	1 2 3 4 5 6 7 8	Output #1 Output #2 Output #3 Output #4 Output #5 Output #6 Output #7 Output #8 GND	P5-1 P5-2 P5-3 P5-4 P5-5 P5-6 P5-7 P5-8 P5-9

P207 (connect to P8) Phone Line I/O

Pin#	<u>Description</u>	FF-800 pin	Pin#	Description
1	Busy(+) Input	P8-4	1	+12V Input
2	Busy(-) Input	P8-5	2	+12V Input
3	In Use (+) Output	P8-6	3	Switched +1
4	In Use (-) Output	P8-7	4	Switched +5
5	. , ,		5	Switched -5V
6			6	GND
7			7	GND
8			8	GND
9	GND		9	GND

1	+12V Input	n/a
2	+12V Input	n/a
3	Switched +12V Output	P1-5
4	Switched +5V Output	P1-6
5	Switched -5V Output	P1-7
6	GND	P1-1
7	GND	P1-2
8	GND	P1-3
9	GND	

FF-800 pin



Used on P201-207





Figure 3. DB-9 cable prep and pinout



P208 (switch module)

Power


DB9 Female wiring side

Used on P208

Figure 4 illustrates the wiring of the RS-232 serial connector, P210. The chassis connector is a female DB-25 wired as a DCE (Date Communications Equipment). This connection is ready to connect to any DTE device such as a terminal or PC. If the FF-800 is to connect to another DCE type device (ie., a modem or TNC) the user must supply a null modem cable or adapter (available from Radio Shack or other electronics outlet).

DB-25 pin	<u>Description</u>	
2	RXD (TO FF-800)	
3	TXD (FROM FF-800)	
4	pin 5 *	* Note: For FF-800 revH or later, these
5	pin 4 *	jumpers may be located located near P27a
6	pins 8 & 20 *	on the FF-800 board
7	GND	
8	pins 6 & 20 *	
20	pins 6 & 8 *	

all others are N/C



DB25 Female

Figure 4. RS-232 chassis connector (DB-25 female, wiring side view)





Figure 5. RS-232 cable connector (DB-25 male, wiring side view)

9-pin DSUB COM port connection:

P27-1 to DSUB(female)-3 (FF800-RXD) P27-2 to DSUB(female)-2 (FF800-TXD) P27-3 to DSUB(female)-5 (GND)

Figure 5b. 9-pin RS-232 connector



FF-800 mini-DIN Connector Pinouts

The following tables describe the mini-DIN connector pinouts for the FF-800:





Figure 6. Four (4) pin mini-DIN connector, wiring side view Figure 7. Six (6) pin mini-DIN connector wiring side view

Port A	A Receiver P11:	Port B	Receiver P12:
<u>Pin</u>	<u>Description</u>	<u>Pin</u>	<u>Description</u>
1	COS (in)	1	COS
2	RX Audio (in)	2	RX Audio
3	GND	3	GND
4	Port A CTCSS (in)	4	Port B CTCSS

Port	C Receiver P13:	Port D	Receiver P14:
<u>Pin</u>	<u>Description</u>	<u>Pin</u>	<u>Description</u>
1	COS	1	COS
2	RX Audio	2	RX Audio
3	GND	3	GND
4	Port C CTCSS	4	Port D CTCSS

Port A	Transmitter P15:	Port B	Transmitter P16:
<u>Pin</u>	<u>Description</u>	<u>Pin</u>	<u>Description</u>
1	PTT (out)	1	PTT
2	TX Audio (out)	2	TX Audio
3	GND	3	GND
4	Logic Out 1 (out)	4	Logic Out 2


Port C	C Transmitter P17:	Port D	Transmitter P18:
<u>Pin</u>	<u>Description</u>	<u>Pin</u>	<u>Description</u>
1	PTT	1	PTT
2	TX Audio	2	TX Audio
3	GND	3	GND
4	Logic Out 3	4	Logic Out 4

Aux.	DVR Audio P20:	Link	Patch P24:
<u>Pin</u>	Description	<u>Pin</u>	<u>Description</u>
1	Chan. A Record Audio (out)	1	GND
2	DVR Play audio (in)	2	~Patch_Busy (in)
3	GND	3	Aux. Patch Audio (in)
4	Chan. B Record Audio (out)	4	~RING (out)
		5	Repeater Audio (out)
		6	~Off_Hook (out)

Note: (in) and (out) signal directions are from the perspective of the FF-800.

mini-DIN Connector Assembly Detail

The mini-DIN connectors are comprised of a contact array, two metal inner shells, two plastic outer shells, and a plastic connector housing. Figure 10 illustrates the pin diagrams for both the 4 pin and 6 pin connectors.



There are two steps to assembling the mini-DIN connectors: the inner assembly and the outer assembly. The inner assembly involves cable preparation and connection and figure 11 illustrates the steps involved. First, prepare the cable (preferably shielded) by exposing 3/8" of the conductors as shown. Next, place the outer hood over the cable (see figure 12) and attach the wires to the contact assembly. Be sure to note the color code of each connection for later reference. Next, place a small piece of electrical tape around the soldered connections -- one wrap is sufficient, too much tape will prevent the top and bottom shells from mating properly.

Mini DIN Inner Shell Assembly




Figure 11. Assembly details of the inner portion of a 4 pin mini-DIN male connector. The details for the 6 pin mini-DIN are similar except for the pin pattern.

Place the top and bottom shells around the contact assembly and then do the same with the left and right shells (as shown in figure 12). Be sure to properly orient the left and right shells as shown or they wll not mate properly. Finally, push the connector housing over

the outer shells until it is flush with the inner shells at location (A) in figure 12. Be sure to hold the outer shells in place until the connector housing is pressed into place. Once the assembly is complete, the connector is ready to install -- the alignment mark on the connector housing should point "up" when inserting into the female mini-DIN connectors.

Mini DIN Outer Shell Assembly





Figure 12. Assembly details of the outer portion of the mini-DIN male connector. The connector housing slides over the completed assembly.

Molex Connector Assembly Detail



Most connections to the FF-800 board are made via Molex connectors (supplied) -- although the transmitter and receiver connections are duplicated using a 4 pin "mini-DIN" style connector. The Molex connectors are easily installed once the method of attaching the pin inserts is mastered. Figure 8 illustrates a typical Molex pin insert. Notice that there are two flanges near one end of each pin insert. Prepare each wire to be attached by stripping 0.1" of insulation -- do not pre-tin conductors.

The wires are attached by crimping the inner flange (1) on the exposed conductor and then applying a small amount of solder to secure the connection. Once the connection has

cooled, the outer flange (2) is crimped around the insulation to provide strain relief. If an appropriate crimp tool is not available, use a pair of medium needle-nose pliers to carefully bend the flanges around the conductor. Make sure that the crimped connection is reasonably secure before soldering.

If too much solder is applied to the connection, excess solder may wick up to the contact loop (3) and/or the locking clip (4). If this happens, the pin insert is ruined and must be replaced. Only use the minimum amount of solder and heat to establish a good electrical connection.

Figure 9 illustrates a typical Molex housing. Pin one is located by orienting the housing as shown. Alternately, the last pin (opposite of pin 1) on the housing can be located by looking at the bottom face of the housing. For a 9 pin housing, the number "9" is imprinted in the housing next to the appropriate hole, a 7 pin housing has a "7", and so on.... Thus pin 1 is the hole at the opposite end of the housing.





Figure 9. Molex Housing

Doug Hall RBI-1 Connection


The FF-800 includes all the software needed to interface to the Doug Hall RBI-1 Kenwood radio interface. However, some additional hardware is required to allow the interface to work properly. The schematic on the next page illustrates the recommended hardware connections to interface the RBI-1 to the FF-800 SPI bus.



FF-8010 Display Module

Microphone Header Wiring

The FF-8010 microphone preamplifer includes an 8-pin microphone plug that allows any standard DTMF microphone to be used with the system. A 16 pin DIP header allows the FF-8010 to be "programmed" to the pinout desired. Pins 1 through 8 of the header correspond with pins 1 through 8 of the microphone connector. Pins 13 through 16 correspond to the FF-8010 pre-amp inputs. By connecting the pre-amp header pins to the corresponding microphone header pins, the microphone connection to the FF-8010 is completed (up/down buttons, etc... are not connected). The table below lists some of the more popular microphone formats along with the header wiring for each.




16 pin DIP Header (top view)


Figure 1. Kenwood MC-48 header wiring.


		ICOM	Kenwood	
Description	Header pin	<u>HM-23</u>	MC-48	<u>Alinco</u>
Mic. Power	16	2	5	5
Mic. Audio	15	1	1	1
Mic. GND	14	7 & 6	7 & 8	7 & 8
Mic. PTT	13	5	2	2

FF-8010 Parts List

C101, 104, C110 C102, 103, 105 C106 C107, 108, 109	10 uF electrolytic capacitor, 25V 0.1uF ceramic capacitor, 50V 1.0 uF non-polarized electrolytic capacitor, 35V 100pF ceramic capacitor, 50V
R101, 102, 109	1K ohm resistor, 1/4W
R103, 105	10K ohm resistor, 1/4W
R104	100K ohm resistor, 1/4W
R106	51K ohm resistor, 1/4W
R107	100 ohm resistor, 1/4W
R108	2.2K ohm resistor, 1/4W
R110	510 ohm resistor, 1/4W
U101, 102	MC14489A LED Driver I.C.
U103	LM78L05 5V regulator I.C.
U104	LF353 (or equivalent) op-amp I.C.
D101-108, 117-119, 122-130	Green LED
D109-116, 120-121,139-142, 145	Red LED
D131-138, 143-144	Yellow LED
J1	16 pin DIP header







FFlash (rev C) Module

FFlash (revC) Parts List

C1, 2	22pF ceramic capacitor, 0603 pkg
C3, 4, 5, 6	10 uF electrolytic capacitor, 16V
C7, 8	0.1 uF ceramic capacitor, 1206 pkg
D1	Amber LED, 1206 pkg
D2	Red LED, 1206 pkg
P1	10 pin IDC header
Q1	2N2907, SOT-23 pkg
Q2	2N2222, SOT-23 pkg
R1	10M resistor, 0603 pkg
R2, 3	68K resistor, 0603 pkg
R4, 5, 8, 9, 10	4.7K resistor, 0603 pkg
R6, 7	470 resistor, 1206 pkg
R11, 12	1K resistor, 0603 pkg
R13	100K resistor, 0603 pkg
SW1	Push-button switch
U1 U2	MC68HC908 Microcontroller I.C. MAX662 DC-DC converter I.C.
Y1	4.915MHz crystal


Jumper Options

J1 selects the factory initialize option. No jumper, or a jumper at position 2-3 selects normal operation. A jumper at position 1-2 sets the factory initialize mode -- if a reset is activated, the FF-800 will enter its factory initialize routine which resets the controller configuration. Jumper position 1-2 is only a temporary selection, it should not be selected for normal operation.


J2 selects the baud rate for the serial command detect feature. J2 is a series of jumper pads which are either open, or connected with a solder "blob". If all of the positions are open, the 9600 baud rate is selected. The 1200 pad selects 1200 baud, the next pad selects 2400 baud, and the next pad selects 300 baud. The 9600 baud pad is obstructed by P1 and is not used (select no pad for 9600).

The "irq" pads just above U1 allow the FFlash serial command password to be reset. Temporarily short these two pads together and apply power. The MODE LED will flash "O K" in CW to indicate that the erase operation is complete.

See the FFlash Operations Manual for more information regarding the FFlash commands and options.



FFLASH Rev C Layout



FFLASH Rev-C Install Notes DOC date: 10/13/24, REV -

The FFLASH is a small control board that allows the software load of the FF-800 repeater controllers. It controls the reset modes and facilitates the programming configuration process. It is intended to attach to an unused DB-9 cutout on the FF-180 (or similar) chassis. Since the Revision C device allows the reset of the FF-800 to be accomplished using serial commands (<CTRL-Y> sequences), it is not required that the module be accessible via a DB-9 style cutout. This can be useful in the event that there is not a suitable cutout available. The photo below illustrates a typical mounting scenario.

A 10-conductor ribbon cable connects the FFLASH P1 to the FF-800 P28 connector (P28b on FF-800 boards with revision F artwork and a U29 interposer).



Photo: FFLASH FF-180 Chassis mounting.